

How to trigger alarm inputs on SVD range

First let's setup the SVD - Use default password 6666 to access the menu.

Navigate to Alarm, then Sensor.

Choose your settings in the **Sensor** menu, as follows:

Channel = Alarm input cable.*Sensor 1 should be connected to Reverse trigger as this sensor has the priority always.

Enable = If the Sensor is enabled.

Sensor name = This can be whatever the user wants.

Trigger Level = If your trigger is High or Low.

Linkage = Video Channel that will be called when the trigger is active.


OSD = If you want the OSD to be shown on alarm

Alarm = If the event will be recorded as alarm


Lock = If you want the screen to lock on this channel


Alarm out = If you want an alarm out to be triggered

Once you have set the sensor as you want click **SAVE** and then **OK**.



Simply apply voltage (between 5 and 24V MAX-NO MORE THAN 24V) to the blue cables which you have setup your sensors to trigger.





You can change the Alarm out time and what triggers the alarm:

Login > Navigate to **Alarm**, then **Other**.

Choose your settings in the menu, as follows:

Alarm out time = How long the alarm will trigger for. **Low voltage** = Detects when vehicle battery is low and will alarm output *This is not supported.

Low Speed = If low speed will trigger and set a value. **High Speed** = If high speed will trigger and set a value.

Alarm out enable*:

Speed


G-Sensor

Video Lost

MD (motion detection)

HDD Fail

Power



*If you tick too many of these you will not be able to confirm what the trigger was.

Once you have set the sensor as you want click **OK**.